

輸出

**Bypass / High Current**

後級

環繞聲擴音機

單件器材耗電量大於以下數值時，建議使用 Bypass / High Current 插位

S 20A	600W
S 30A	800W
S 60A	800W
Gateway2	1800W

**Digital**

解碼

藍光機

CD播放機

串流播放器

**Analog**

前級

電視/投影機

唱頭放大器

有源喇叭

擴音機

Soundbar

**⚠ 注意事項**


請執行以下安全事項並正確使用器材，以免造成身體受傷、及財物損毀。

1. 使用本產品前，請仔細閱讀操作說明並遵循安全守則操作。
2. 確保本產品遠離水及濕氣，否則將可能引起漏電、火災或觸電。
3. 應把本產品放置在通風良好的地方使用。切勿放置在密封空間，阻止散熱。
4. 切勿將本產品靠近熱源，如散熱器、火爐，或其它能產生熱量的設備。
5. 若長時間不使用本產品，請拔下電源線。
6. 必須按照使用地區標準接好相線，不得以零線代替地線，以防關機後有迴路電。



**Power Makes the Difference**

本手冊上的資料，如有出入，以英文版為準。另本公司會不時更新產品的零件及規格，以求完善產品。故最新的產品在規格上可能與本手冊的資料有所出入，敬希諒解。



output

### Bypass / High Current

Power AMP

AV AMP

For equipments consumes power over the below figures, please use Bypass / High Current

S 20A	600W
S 30A	800W
S 60A	800W
Gateway 2	1800W

### Digital

DAC

Blu-ray  
Player

CD Player

Streamer

### Analog

PRE AMP

TV / Projector

Phono AMP

Active  
Speakers

Integrated  
Amp

Soundbar



**Power Makes the Difference**

The information given in this document is correct at the time of print. Small production changes may arise due to our ongoing research and products improvement.

### ⚠ Important Safety Instructions

1. Read and follow Instructions—All safety and operating instructions should be read and followed before operating the device.
2. Water & Moisture—The device should never be used in, on or near water for risk of fatal shock.
3. Ventilation—The device should always be put in a place with proper ventilation. It should never be placed in a built-in installation or anywhere that may block the flow of air.
4. Heat—Never locate the device near heat sources such as radiators, floor registers, stoves or other heat-generating devices.
5. Periods Of Non-Use—The device should be unplugged when not being used for extended periods.